



TRANSVERSE EXPANSION JOINT

NOTES:

- 1. TRANSVERSE EXPANSION JOINTS TO BE A MAXIMUM OF 50 FEET.
- 2. ALL CONCRETE TO BE FINISHED WITH CURING COMPOUND.
- 3. A 6 INCH DEPTH IS REQUIRED.
- 4. SAW CUT JOINTS EVERY 6 FEET OR WIDTH.
- 5. NO UTILITY SURFACE COVERS/PLATES/MANHOLES SHALL BE LOCATED WITHIN TRAIL AND SHALL BE MINIMUM 2 FEET FROM THE EDGE OF TRAIL.



STANDARD 6-FT CONCRETE TRAIL

DETAIL No.

9100.06