



MAINTENANCE:

- 1. INSPECT CHANNEL REGULARLY AND AFTER RAINFALL EVENTS. MAKE NEEDED REPAIRS IMMEDIATELY.
- 2. CHECK FOR INDICATIONS OF PIPING, SCOUR HOLES, OR BANK FAILURES. MAINTAIN ALL VEGETATION ADJACENT TO THE CHANNEL TO PROTECT THE AREA FROM EROSION AND SCOUR.



PARABOLIC-SHAPED



V-SHAPED

TRAPEZOIDAL (TYPICAL RIPRAP CHANNEL)

NOTES:

- 1. TO BE USED WHERE EXCESSIVE STORMWATER VELOCITIES PROHIBIT VEGETATIVE LININGS.
- 2. SIZE OF STONE MUST BE DETERMINED BY APPROPRIATE DESIGN PROCEDURE.
- 3. DIMENSIONS FOR d & W VARIES ACCORDING TO DESIGN.



STANDARD RIPRAP LINED CHANNELS

DETAIL No.

4000.10