



MAINTENANCE:

1. INSPECT WEEKLY AND AFTER EACH RAINFALL EVENT.
2. CLEAR THE WIRE OF ANY DEBRIS OR OTHER OBJECTS TO PROVIDE ADEQUATE FLOW FOR SUBSEQUENT RAINS.
3. TAKE CARE NOT TO DAMAGE OR UNDERCUT THE WIRE AND SILT FENCE FABRIC DURING SEDIMENT REMOVAL.
4. REFRESH AND REPLACE STONE AS NEEDED.



EFFECTIVE: 07/01/23

STANDARD SILT FENCE OUTLET

DETAIL No.

4000.23